



Acoustic House
Bridlington Road
Hunmanby
North Yorkshire
YO14 0PH
United Kingdom

T: 01723 891655
E: sales@cirrusresearch.co.uk
W: www.cirrusresearch.co.uk

18 Pin Multiway
to Optimus



12 Pin RL01 Multiway to
Fujitsu printer.

ZL:182 Optimus Fujitsu Printer cable, 18-way to RL01

Instructions:

- The ZL:182 is a Fujitsu printer cable for a Optimus.
- Plug the 18 pin multi-way connector into your Optimus.
- Connect the 12 pin RL01 multi-way to the Fujitsu printer.
- Ensure the DIP Switch 1 is ON all other switches set to OFF.
- Make a measurement on the Optimus then in the 'Menu' select 'Print'.
- A report of the measurement will be printed.